






























PACKAGE CONTENTS LIST

<p>A. Firebox Assembly-1pc.</p> 	<p>B. Bottom Panel-1pc.</p> 	<p>C. Wheel-2pcs.</p> 
<p>D. Side Burner Shelf & Control Panel-1pc.</p> 	<p>E. Left Side Shelf & Control Panel-1pc.</p> 	<p>F. Cart Leg, Front Left-1pc.</p> 
<p>G. Cart Leg, Back Left-1pc.</p> 	<p>H. Cart Frame, Top-2pcs.</p> 	<p>I. Cart Leg, Front Right-1pc.</p> 
<p>J. Cart Leg, Back Right-1pc.</p> 	<p>K. Cart Caster Insert-2pcs.</p> 	<p>L. Cooking Grids-2pcs.</p> 
<p>M. Side Burner Control Knob-1pc.</p> 	<p>N. Fix Bar-1pc.</p> 	<p>O. Triangle Bracket, Left-1pc.</p> 
<p>P. Triangle Bracket, Right-1pc.</p> 	<p>Q. Tank Bolt-1pc.</p> 	<p>R. Cart Beam-1pc.</p> 
<p>S. Front Panel-1pc.</p> 	<p>T. Condiment Tray-1pc.</p> 	<p>U. Side Tube Burner-1pc.</p> 

V. 1.5 Volt "AA" Size Alkaline Battery-1pc. 	W. Grease Box-1pc. 	X. Grease Tray-1pc. 
Y. Diagonal Bar Barrier-1pc. 	Z. Warming Rack-1pc. 	ZA. Flame Tamers-4pcs. 
ZB. Side Burner Cooking Grid-1pc. 		

HARDWARE CONTENTS - Pre-installed as noted in instructions that follow.


REF#	Description	QTY
AA	5/32-in. x 10-mm Truss Head Screw	36pcs.
BB	5/32-in. x 9/16-in. Truss Head Screw	2pcs.
CC	1/4-in. x 15-mm Truss Head Screw with Washer	18pcs.
DD	1/4-in. Flat Washer	16pcs.
EE	1/4-in. Axle Flat Washer	2pcs.
FF	1/4-in. Nut	2pcs.



AA



BB



CC



DD



EE




FF


PREPARATION

Before beginning assembly, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

- Estimated Assembly Time: 40 minutes
- Tools Required for Assembly:



Phillips Screwdriver



Wrench

Phillips Screwdriver (not included) and Wrench (not included)


- Note: The right and left sides of the grill are designated as if you are facing the front of the grill.

REPLACEMENT PARTS LIST

For replacement parts, call our customer service department at 1-800-913-8999 in USA, 7 a.m. – 5 p.m., PST, Monday – Friday.

REF#	DESCRIPTION	WARRANTY COVERAGE	QTY	REF#	DESCRIPTION	WARRANTY COVERAGE	QTY
01	Main Lid	1yr	1pc	30	Lighting Rod	1yr	1pc
02	Hood Buffer B	1yr	2pcs	31	Cart Caster Insert	1yr	2pcs
03	Main Lid Screw	1yr	2pcs	32Q	Bottom Panel, LP	1yr	1pc
04	Temperature Gauge	1yr	1pc	33Q	Cart Frame	1yr	2pcs
05	Logo	1yr	1pc	34Q	Cart Leg Rear, Right	1yr	1pc
06	Flame Tamer	1yr	4pcs	35Q	Cart Leg Front, Right	1yr	1pc
07	Cooking Grid w/ Hole	1yr	2pcs	36	Wheel	1yr	2pcs
08	Warming Rack	1yr	1pc	37	Diagonal Bar Barrier	1yr	1pc
09	Main Lid Handle Seat, Left	1yr	1pc	38	Condiment Tray	1yr	1pc
10	Main Lid Handle Seat, Right	1yr	1pc	39	Fix Bar	1yr	1pc
11	Main Lid Handle Tube	1yr	1pc	40	Front Panel	1yr	1pc
12	Hood Buffer A	1yr	2pcs	41	Tank Bolt	1yr	1pc
13Q	Main Burner Bowl Assembly	Non-replaceable	1pc	42Q	Cart Frame, Rear	1yr	1pc
14Q	Front Baffle	1yr	1pc	43Q	Side Burner Control Panel	1yr	1pc
15	Main Gas Valve	1yr	5pcs	44	Side Burner Pipe	1yr	1pc
16	Pulse Ignite Module	1yr	1pc	45	Side Burner Igniter Wire	1yr	1pc
17	Regulator, LP	1yr	1pc	46Q	Side Burner Bowl Assembly	1yr	1pc
18	Side Manifold	1yr	1pc	47	Side Burner Cooking Grid	1yr	1pc
19	Side Burner Flex Gas Line	1yr	1pc	48	Side Burner Lid	1yr	1pc
20	Main Manifold	1yr	1pc	49	Side Burner Lid Hinge Rod	1yr	2pcs
21	Main Control Panel	1yr	1pc	50	Side Burner Lid Hinge Rod Pin	1yr	2pcs
22	Bezel	1yr	4pcs	51	Grease Tray	1yr	1pc
23	Control Knob	1yr	5pcs	52	Grease Box	1yr	1pc
24Q	Side Shelf, Left	1yr	1pc	53Q	Main Burner Igniter Wire A	1yr	1pc
25Q	Side Shelf Panel, Front	1yr	1pc	54Q	Main Burner Igniter Wire B	1yr	1pc
26Q	Triangle Bracket, Left	1yr	1pc	55Q	Main Burner Igniter Wire C	1yr	1pc
27Q	Triangle Bracket, Right	1yr	1pc	56Q	Main Burner Igniter Wire D	1yr	1pc
28Q	Cart Leg Front, Left	1yr	1pc	57	Main Burner	3yrs	4pcs
29Q	Cart Leg Rear, Left	1yr	1pc	58	Main Burner Pin Assembly	1yr	4pcs

Parts Diagram



Printed in China